



not found or type unknown

**DOORSCHUIFVAATWASSER MET
WARMTE-TERUGWIN-SYSTEEM**



not found or type unknown

**HOODED DISHWASHER DOUBLE
WALLED DOOR WITH DRAIN PUMP AND HEAT
RECOVERY UNIT**

Het warmte terugwin systeem (WTW) zorgt voor afzuiging en condensatie van de stoom die ontstaat bij het spoelen van de machine.

De warmte die hierbij vrijkomt, verwarmt het koude water met 25 graden. Voordelen zijn 30% energiebesparing m.b.t. het opwarmen van het binnenkomende water.

Door nagenoeg geen vrijkomend condens, wordt een prettige werkomgeving gecreëerd en is een condenskap overbodig.

- Machine vervaardigd van AISI 304 roestvrijstaal
- Machine volledig dubbelwandig
- Boiler en tankverwarming middels Incoloy 800 element
- Standaard geleverd met 2 korven
- Vermogen verwarming tank: 2500 W
- Vermogen verwarming boiler: 8300 W
- Digitale bediening
- Ingebouwde afvoerpomp
- Ingebouwde zeepdoseerpomp
- Pomp voor naspoelelans
- Wascyclus: 60/120/180 seconden
- Capaciteit: 20 tot 60 korven per uur
- Tankinhoud: 26 liter
- Waterverbruik per wasbeurt: 3 liter
- Tank voorzien van roestvrijstalen filters
- Tank makkelijk bereikbaar
- Spanning: 400 V / 50 Hz
- Vermogen: 8.900 W
- Afmeting: 626 x 755 x 2155 mm (BxDxH)
- Gewicht: 200 Kg

Advies: Waterinvoer tussen de 10-40 ° C

- Voorbereid voor aan/afvoertafels

- GEEN INFORMATIE OVER WTW-SYSTEEM!!!!

Artikel referentie : CLVACDPVRC
EAN : 3611630038775

- Chassis and body : AISI 304 stainless steel
- Washing and rinsing stainless steel arms
- Double walled door and tank
- Digital control
- 3 wash programs
- Tank and boiler heating element : incoloy 800
- Performance : 20 baskets per hour
- Supplied : 2 baskets 500 x 500 mm (22 plates diam 24/basket)
- Tank heating element : 2,5 kW
- Boiler heating element : 8,3 kW
- Boiler holding device
- Boiler thermal insulation device
- Thermostat bowl with fixed setting 55 ° C
- Deep-drawn tank with automatic draining
- Cleaning products batcher
- Rinsing products batcher
- Cycle times : 50/120/180 secondes
- Production : 1320/660/440 basket per hour
- Tank capacity : 26 liters
- Consumption : 3 liters rinsing water
- Stainless steel surface filters in the tank
- Simple-phase predisposition
- Power : 8,9 kW / 400 V
- Dimensions : L 626 x D 755 x H 2155 mm
- Weight : 200 Kg

Advice: supply water 10-40 ° C

> Predisposed for connection to accessories tables (service shelves, garbage tables, etc.)

Article reference : CLVACDPVRC
EAN : 3611630038775